


INSTALLATION OF SECURITY BOLT KIT


This bulletin gives instruction on how to fit the security screw kit. This kit replaces the current caphead socket screw which holds the stabiliser leg in place. It will prevent the unauthorised removal of the stabiliser leg and prevent the use of the machine in this situation.

KIT CONTENTS (figs. 1 & 2)



- 1. Torx T30 Security Screw (4 off)
- 2. M6 Nut (4 off)
- 3. M6 Spring Washer (4 off)

fig. 1



- 4. Torx T30 Security Screw Bit (1 issued per depot)

fig. 2

1. Using a 4mm A/F Allen Key, remove the existing caphead socket screws from the stabiliser leg as shown below (fig.3). Repeat for remaining 3 legs.



fig. 3

3. Apply a few drops of thread-locking solution to the exposed portion of the screw as shown below (fig.5).



fig. 5



fig. 4

2. Assemble the security screws as shown above (fig.4) ready for insertion.



fig. 6

4. Insert and fully tighten the security screw. Leave until threadlocking solution hardens. Repeat for the remaining 3 legs, as shown above (fig.6).